

SLIDING DOOR FLUSH LOCKSET - 390 & 395

Fitting Instructions

390 for 30 to 38mm thick doors

395 for 40 to 48mm thick doors

1. Prepare the door panel, as shown in Diagram 1.
2. Fit the mortice lock case and fix with the wood screws provided.
3. In order to prevent any rotation of the flush pulls we advise you apply silicone on the interior angle, as shown in Diagram 3.
4. Fit the flush pulls into the 48mm holes inserting the square spindle through the mortice lock body and into the opposite flush pull receiver (**the spindle is not to be cut**).
5. Fix the flush pulls together by turning the expanding spindle with a 3mm allen key, as shown in Diagram 3.
6. Make an indent on the jamb frame with the lock striker. Using the mark as the centre point, drill a 25mm hole, 15mm deep. Fit the keep back liner in the hole and screw the keep plate in position with the circular holes in line.
7. Fix the finger pull into the 25mm diameter hole in the edge of the door, as shown in Diagram 2.

